

HOW TO MEASURE A FLAT ROOF

FOLLOW THESE SIMPLE STEPS TO WORK OUT THE SIZE OF THE MEMBRANE AND TRIMS REQUIRED

- MEASURE THE ROOF, i.e. LENGTH x WIDTH (IN METRES)
- ADD 150mm EACH SIDE TO ALLOW THE MEMBRANE TO OVERHANG ANY OPEN FASCIA EDGES & GUTTER EDGES
- ADD THE HEIGHT OF ANY UPSTAND IF THE ROOF ADJOINS A BUILDING, i.e. ATTACHED TO THE HOUSE
- ADD 300mm IF THE MEMBRANE IS TO FINISH UNDER A PITCHED ROOF
- ROUND UP THE MEASUREMENTS TO THE NEAREST METRE, i.e. 5.8m x 2.9m WILL NEED TO BE ROUNDED UP TO 6m x 3m

THEN

- MEASURE ANY EDGES WHERE TRIMS ARE REQUIRED (FASCIA EDGES) IN METRES
- MEASURE ANY GUTTER EDGES IN METRES
- CHOOSE THE TYPE OF TRIM YOU REQUIRE, Upvc QUICKTRIM OR PLASTISOL METAL. (Black or White)

THEN

- DETERMINE THE TYPE OF DECK YOU WILL BE BONDING TO
- WATER BASED ADHESIVE ONTO FLAT TIMBER DECK
- BONDING ADHESIVE TO ANY OTHER SURFACE
- CALCULATE THE QUANTITY OF ADHESIVE REQUIRED

WATER BASED ADHESIVE – COVERAGE APPROX 4m² per Litre

BONDING ADHESIVE – COVERAGE APPROX 2m² per Litre

FINALLY

- CHECK FOR ANY PIPE DETAILS, SKYLIGHTS AND EXTERNAL CORNERS.

MATERIALS CHECK LIST

EPDM MEMBRANE CUT TO SIZE

WATER BASED ADHESIVE

BONDING ADHESIVE

EDGE TRIM

GUTTER TRIM

FIXINGS

EXTRAS – PIPE FLASHING, FORMFLASH (corners), WALL FLASHINGS, QUICKPRIME PLUS

ALL THE ITEMS LISTED ABOVE ARE AVAILABLE ONLINE 24 HOURS A DAY, IF YOU NEED ANY HELP PLACING AN ORDER PLEASE DO NOT HESITATE TO CONTACT US.